

FIG. 1

2/5

40

USER ID	PERMITTED LOCATIONS
USER 1	LOC1, LOC3, LOC5 — LOC7
USER 2	LOC2, LOC9
USER 3	LOC1 — LOC9
⋮	
USER N	LOC7, LOC9

FIG. 2




FIG. 3

3/5

```
#####  
# VSA Dictionary  
#####  
# Use the Radius specification attributes  
#  
@radius.dct  
  
#  
# Extreme Networks Vendor Specific Attributes below:  
#  
  
MACRO   Extreme-VSA(t,s)  26  [vid=1916 typel=%t% lenl=+2 data=%s%]  
  
ATTRIBUTE      Extreme-CLI-Authorization      Extreme-VSA(201, integer) Cr  
VALUE          Extreme-CLI-Authorization      Disable    0  
VALUE          Extreme-CLI-Authorization      Enable     1  
  
ATTRIBUTE      Extreme-Netlogin-Only          Extreme-VSA(206, integer) Cr  
VALUE          Extreme-Netlogin-Only          Disable    0  
VALUE          Extreme-Netlogin-Only          Enable     1  
  
ATTRIBUTE      Extreme-Shell-Command          Extreme-VSA(202, string) Cr  
  
ATTRIBUTE      Extreme-Netlogin-Vlan          Extreme-VSA(203, string) Cr  
  
ATTRIBUTE      Extreme-Netlogin-Url           Extreme-VSA(204, string) Cr  
  
ATTRIBUTE      Extreme-Netlogin-Url-Desc      Extreme-VSA(205, string) Cr  
  
ATTRIBUTE      Extreme-Netlogin-Only          Extreme-VSA(206, integer) Cr  
  
ATTRIBUTE      Extreme-Netlogin-Dot1P-Tag     Extreme-VSA(207, integer) Cr  
  
ATTRIBUTE      Extreme-User-Location          Extreme-VSA(208, string) Cr  
  
ATTRIBUTE      Extreme-Netlogin-VLAN-Tag      Extreme-VSA(209, integer) Cr  
  
#####  
# VSA Dictionary  
#####
```

FIG. 4

4/5

File Help

☐ Servers
☐ RAS Clients
☒ Users
☐ Profiles
☐ Proxy
☐ Tunnels
☐ IP Pools
☐ IPX Pools
☐ Access
☐ Configuration
☐ Statistics

User Name: \\JAREDNMS\EAP-TTLS USERS Add Remove

User Type: NT Domain Group Set password

Check list attributes Return list attributes

Extreme-Use-Location jared-ap1

Ins Edit Del

☐ Maximum concurrent connection

Profile name: <no profile>

Save Reset

Add New Attribute

Available attributes:

- Extreme-Netlogin-Uri
- Extreme-Netlogin-Uri-Desc
- Extreme-Netlogin-Vlan
- Extreme-Netlogin-VLAN-Tag
- Extreme-Shell-Command
- Extreme-User-Location
- Framed-Compression

Enter a string: your_ap_location_here Add Close

Multi-Valued Orderable ☐ Default

FIG. 5

5/5




FIG. 6A




FIG. 6B




FIG. 6C